

EX Instructions

Number of EC type examination certificate


KEMA 02 ATEX 1090 X

Amendment to operating instructions for these type series

Type	Description	Instructions
BE2xxx	Pressure gauges with switch function	BA_037
BE4xxx		
BF2xxx		
BGxxxx		
BR42xx		
FPxxxx	Mechanical thermometers with switch function	BA_066
FUxxxx		

Marking

 II 1 G Ex ia IIC T4/T5/T6 Ga

 II 1 D Ex ia IIIC T95°C Da

- BG: Ако не разбирате указанията за безопасност, можете да изискате превод на вашия език.
- CZ: Pokud těmto bezpečnostním pokynům nerozumíte, můžete si vyžádat jejich překlad do vašeho jazyka.
- DA: Hvis du ikke forstår sikkerhedshenvisningerne, kan du forespørge en oversættelse i dit sprog.
- DE: Wenn Sie diese Sicherheitshinweise nicht verstehen, können Sie eine Übersetzung in Ihrer Landessprache anfordern.
- EL: Εάν δεν καταλαβαίνετε αυτές τις υποδείξεις ασφαλείας, μπορείτε να ζητήσετε μια μετάφραση στη μητρική σας γλώσσα
- ES: Si no entiendes estas indicaciones de seguridad, puede solicitar una traducción en su idioma.
- ET: Kui need ohutusnõuded ei ole teile arusaadavad, võite tellida meilt tõlke oma keelde.
- FI: Jos et ymmärrä näitä turvaohjeita, voi pyytää ne lähetettäväksi omalle kielellesi käännettynä.
- FR: Si vous ne comprenez pas les consignes de sécurité, vous pouvez faire la demande d'une traduction dans votre langue.
- HU: Amennyiben nem érti ezeket a biztonsági utasításokat, akkor kérheti ezeknek az Ön nyelvére lefordított változatát.
- IT: Nel caso non capite queste avvertenze di sicurezza, ne potete richiedere una traduzione nella vs. lingua.
- LT: Jei nesuprantate šių saugos reikalavimų, galite užsisakyti jų vertimą į Jūsų kalbą.
- LV: Ja jūs nesaprotat šos drošības norādījumus, jūs varat pieprasīt tulkojumu jūsu valodā.
- NL: Indien u deze veiligheidsinstructies niet begrijpt, kunt u een vertaling in uw eigen taal aanvragen.
- PL: Jeżeli niniejsze przepisy bezpieczeństwa są niezrozumiałe, można poprosić o tłumaczenie we własnym języku.
- PT: Se não compreender os avisos de segurança, pode solicitar uma tradução no seu idioma.
- RO: Dacă nu înțelegeți aceste instrucțiuni de siguranță puteți cere traducerea acestora în limba dvs.
- SK: Ak ste nepochopili bezpečnostné pokyny, môžete si vyžiadať preklad do svojho jazyka.
- SL: Če teh navodil ne razumete, lahko zahtevate prevod v Vaš jezik.
- SV: Om du inte förstår den här säkerhetsanvisningen kan du begära att få en översättning till ditt språk.

1 General Safety Notes

The installation, set up, service or disassembly of this device must only be done by trained, qualified personnel using suitable equipment and authorized to do so.



Warning

Media can escape if unsuitable devices are used or if the installation is not correct.

Danger of severe injury or damage

- Ensure that the device is suitable for the process and undamaged.

Measuring devices in explosive environments must be installed and commissioned by competent personnel that are familiar with the specialties of explosion protection. Modifications or damage of devices or electrical connections might negatively influence the operating safety or the ex-proofing.

Observe the regulations and standards for erection and operation of electrical installations in explosive atmospheres as well as the installation and safety notes in the corresponding operation instructions.

Avoid electrostatic charge on plastic surfaces, if present.

2 Requirements for intrinsically safe supply

Connect the gauges to a certified intrinsically safe power circuit.

The following maximum connected values apply to the inductive contact power circuit:

$$U_i \leq 20 \text{ V}$$

$$I_i \leq 60 \text{ mA}$$

$$P_i \leq 130 \text{ mW (T5/T6)}$$

$$P_i \leq 200 \text{ mW (T4)}$$

Effective internal inductance:

$$L_i \leq 350 \text{ } \mu\text{H}$$

Effective internal capacity:

$$C_i \leq 250 \text{ nF}$$

3 Permissible ambient temperatures

Type	Marking	Class	Ambient
All	II 1 G	T4	-25...80 °C
		T5	-25...80 °C
		T6	-25...70 °C
	II 1 D	95 °C	-25...70 °C
	II 2 G	T4	-25...100 °C
		T5	-25...85 °C
T6		-25...70 °C	

For temperature classes T1 to T3 the temperature limits for T4 apply.

4 General information

The EC-Type Examination Certificate KEMA 02 ATEX 1090 X includes numerous design series. The "X" at the end of the certificate number indicates special conditions for safe use. Special conditions don't apply for type Si2-K08-Y1.